



Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion, within the one-year warranty period. Proof of purchase, with the date of purchase as well as photos of the defective merchandise, must be provided.

If you have any questions, comments or concerns please feel free to contact us by phone at: **888-881-4668**. You may also contact us by email: [customerservice@serenityhealth.com](mailto:customerservice@serenityhealth.com), or via our webpage at: [www.serenityhealth.com/contact-us/](http://www.serenityhealth.com/contact-us/)

## GSI-328

### Warning

- Keep fountain out of reach of children.
- Use proper power source as indicated on water pump label.
- Keep electrical cords away from all heat sources. Do not place electrical cords in high temperatures.
- Check water level at pump location regularly, avoid damage the pump must be fully submerged.

### PARTS:

- A. Basin -1pc
- B. Pump and Transformer with spot light -1pc
- C. Fountain body-1pc
- D. Pebbles-1 bag

### ASSEMBLY:

1. Insert the pump into the basin and connect the pump with the hose.
2. Connect the transformer.
3. Put the fountain body onto the basin.
4. Insert the spot light to the top of the fountain body.
5. Place pebbles on top of the basin, and spread out.
6. Fill with water, and then plug fountain into electrical outlet.

### Troubleshooting:

**Pump operates but no water flow:** Make sure pump is fully submerged in water. If there is still no water flow, please turn pump on then off several times.

**Water speed:** Adjust the switch control located on the pump housing.

**Noise from pump/Fountain:** Make sure pump is fully submerged in water.

**Light does not shimmer:** Check the light bulb to make sure that it is connected to socket.

