


# INDOOR/OUTDOOR DINING TABLE WITH WOOD TOP

Read all assembly and care instructions carefully before using this product. Save this manual for future reference.  
**Assemble components on a soft, clean surface to avoid damaging the finish.**



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.

PARTS	QTY.
Tabletop	1
Leg	4
M4.2x22 Button Head Self-Tapping Screw	12
M5x40 Log Screw	16

**TOOLS REQUIRED (NOT INCLUDED)**



**⚠ WARNING ⚠**

**CHOKING HAZARD** — This item contains small parts that can be swallowed by children. Keep children away during assembly.

# ASSEMBLY

*Read carefully and understand assembly before beginning.*

*Images may vary from actual product - assembly steps are the same for all tables with a wooden top.*

*Ensure screws are firmly fastened, but not over-tightened - failure to do so may cause table to crack and break.*



## STEP 1

Lay the tabletop face down on a soft, clean surface. Insert the legs into the corners of tabletop, as shown.



## STEP 2

Firmly fasten (3) M4.2x22 button head self-tapping screws to the inside of each leg.

Do not over-tighten the screws.



## STEP 3

Firmly fasten (4) M5x40 log screws to the sides of each leg.

Do not over-tighten the screws.



## Care & Maintenance

**SAFE USE:** Never sit or stand on the table.

**INSPECT:** Periodically check assembly points and adjust fittings as necessary.

**COVER:** When not in use, covering the table with a breathable cover will help protect it from the harmful effects of sunlight, dust build-up, and collecting debris.

**WINTER CARE & STORAGE:** Protect this item from inclement weather, especially ice and snow. Move the table to a cool, dry indoor location. Covering the table while in storage is recommended to help prevent dust build-up.

## Cleaning

*Do not use harsh chemicals or abrasive materials to clean the table.*

 DO NOT USE BLEACH

 DO NOT USE A PRESSURE WASHER

**Wooden Tabletop:** Use a soft cloth and clean water to wash the wooden surface; do not use detergent, chemicals or abrasive materials on the wooden surface. Thoroughly dry with a soft towel.

**Table Frame:** Mix mild soap with warm of warm water, then wash the table frame using a soft cloth. Thoroughly rinse soap residue off the table. Dry with a soft towel.

Any modification or failure to follow the recommended care will void the product warranty.

## WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.