

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty>. If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>



BOOK WORM BERNARD GARDEN GNOME WITH SOLAR LIGHT

WNC-399

Read the instructions carefully and follow the care instructions. Keep these instructions for future reference.

HOW SOLAR LIGHTS WORK

During the day, the solar panel converts solar energy into electricity and stores it in the rechargeable battery. At night, the light turns on automatically via a light detecting sensor built into the unit. How long the light illuminates will depend upon the location of the light, weather conditions, and how much direct sunlight the unit is exposed to. Ensure the power is switched to 'ON' while charging.

CHOOSING THE RIGHT LOCATION

- Select an outdoor location where the solar panel will receive at least 6-8 hours of full, direct sunshine each day. Ensure the solar panel is not shaded by trees, shrubs, or building shadows throughout the day as this will influence the charge of the battery and shorten the working time at night.
- Avoid locations with strong nighttime light sources nearby, such as street or porch lights. If the light detecting sensor receives too much ambient light, the solar light will turn off.

ACCESSING & REPLACING THE BATTERY

1. Switch the power OFF.
2. Carefully remove the screws from the battery housing on the solar panel.
3. Gently remove the old battery.
4. Paying attention to the positive and negative terminals, gently insert the new battery.
5. Carefully reassemble the battery housing. Screws must be tight to prevent water from getting into the battery housing.
6. The solar panel will require at least 8 hours of full, direct sunlight to fully charge the battery.


⚠ IMPORTANT INFORMATION ⚠

USE & CARE

- Solar function designed for outdoor use only.
- Keep the solar panel clean by wiping it down with a damp cloth; clean solar panels absorb more sunlight.
- Never use chemicals or abrasive materials to clean the unit.
- Do not allow the unit to freeze; store indoors during freezing weather. Remember to turn the unit off before storing.
- Only use compatible rechargeable batteries; incompatible batteries may damage the product and void the product warranty.

TROUBLESHOOTING

- Ensure the power button is in the 'ON' position.
- The light was designed to illuminate at night only, make sure the light sensor is not receiving too much ambient light.
- If the light only works for a short period of time, attempt a 'Boost Charge.'
 - Turn the power 'ON' and let it charge in full, direct sunlight for at least 8 hours.
 - Turn the power 'OFF' at night to conserve the battery.
 - Repeat this process for 2-3 days. If the unit still does not work, the battery may need replacing.

 This product uses a rechargeable battery. When the battery is no longer usable, it should be removed from the unit and recycled. The battery must not be incinerated or composted. Recycle the battery in accordance with local laws and regulations.

Any modification to the product or failure to follow recommended care will void the product warranty.